

HOWO Recovery Truck With Crane

16Tons Capacity & XCMG SQS350 14tons Boom Crane

User's Manual



Wrecker Truck with Crane

OWNER'S MANUAL

Preface

Thank you for purchasing CS TRUCKS products. For better using your HOWO 6X4 Road Wrecker Truck with XCMG Crane, get the best operating performance, we strongly suggest that before the operation process you could read this manual instructions carefully, and to manipulate the program handily.

The manual detailed describes the performance of wrecker truck with crane, structure, usage, precautions and maintenance of such knowledge. While showing details of the truck, both pictures and description will together help you get better understanding of how to use truck. Before the operation, the skilled operator should carefully read the contents of the manual.

After master the truck performance characteristics, methods of operation and precautions, then could start to operate this rescue truck. In order to ensure the staff turnover after the operation, and properly use of the truck. This manual book must be properly kept, shall not be lost and damage.

----CS TRUCKS

Contents

Chapter 1. General Description	5
Chapter 2, Main Technical Data.....	6
Chapter 3, Wrecker Truck with Crane Structure Components.....	7
i , 5 Tons Knuckle Boom Crane	7
ii ,Wrecker Platform Structure Components.....	8
Chapter 4, Wrecker Truck with Crane Working Principles.....	12
i , How is the wrecker truck with crane working?.....	12
ii How to operate wrecker truck with crane?. (Very Important).....	13
Chapter 5, Others for Attention	19
Chapter 6, Troubleshooting	21
Chapter 7, Accessories.....	22

Chapter 1. General Description

CS TRUCKS Wrecker Truck with Crane based on type II SINOTRUK HOWO 6x4 model truck chassis, which consist of 14Tons XCMG SQS350 model telescopic boom crane & over 7m rescue platform, mainly used for road rescue working, and the working aerial can be City Street, factory and other areas of need.

The vehicle designed to fully rely on the advantages of the original 6x4 long wheelbase chassis, fully consider the product's convenience and features. The 14Tons XCMG SQS350 model straight boom crane is supposed to take up little space but with multi-function performance. The rescue platform can be laid down to deliver all kinds of vehicles, with wire rope and tape to fasten the vehicle during delivery, which is multifunctional enough to cover all customers' requirement.

The HOWO 6x4 Tow Truck with Crane equipped with telescopic boom crane, long rescue platform, hydraulic cylinders and English version operation guidance. Therefore, the vehicle is an ideal truck mainly for motor vehicles transportation & vehicles that broke down.



(Preview for your HOWO Recovery Tow Truck with Crane)

Chapter 2, Main Technical Data

Basic parameter:

Items		16Tons ISUZU Flatbed Wrecker Truck with Crane
S I Z E	Outer Dimension (L×W×H) (mm)	12000*2500*3950
	Wheelbase (mm)	5825+1350
Kerb Weight (kg)		16500
G E A R	Gearbox brand	HW19710
	Model	10-shift gearbox with 10F & 2R
	Type	Manual
Cab capacity (includes driver)		2
E N G I N	Model	WEICHAI WP7H320E62
	Type	Six cylinder inline, four stroke, water-cool, turbocharged Inter-cooling, diesel
	Rating Power (kW/HP)	235/320
	Emission Standard	Euro 6 with emission 6800cc

Note: 1. The vehicle height includes Telescopic Boom Crane.

2. We keep the right to revise the parameters on the list above.

Superstructure parameter list

Items		Parameter
Telescopi c Boom Crane SQS350	Capacity (Tons)	5
	Max Lifting Moment	35 T.M
	Max Hydraulic Outreach	16.1 m
	Max Working Height	17.3 m
	Rated Power	55 kW
	Stabilizer Spread	7400 mm
	Fitting Space Required	1200 mm
	Width Folded	2480 mm
	Max Operating Pressure	26 Mpa
	Recommended Pump Capacity	63+50 L/min
Wrecker Platform	Platform Dimension	8500*2300
	Control	Hydraulic Manual control
Remarks		All basic necessary accessories. Tool kit
More details for wrecker truck with crane showing as below		

Chapter 3, Wrecker Truck with Crane Structure Components

i , 14 Tons Telescopic Boom Crane

Side view for HOWO 6x4 flatbed rescue wrecker truck with crane:



The 14Tons telescopic boom crane use famous XCMG brand, with new model SQS350. This consists of telescopic hydraulic arms, rotation seat, hook, hydraulic landing legs, operation joysticks, etc.



ii ,Wrecker Platform Structure Components

This wrecker truck use 16Tons folding type flatbed platform, which mainly consist of below system:

1. Pillow alarm light and fixture (including cabin alarm system)
2. High position traffic signal indicator light at two sides
3. Capstan and rope
4. Platform
5. Side warning lamps
6. Wheel bracket
7. Operation Joysticks
8. Side fence
9. Tool box and accessories



1. Pillow alarm light and fixture (including cabin alarm system)
 Light uninstalled, as package in cabin

Pillow alarm light



2. High position traffic signal indicator light at two sides

Traffic signal light at two sides



3. Capstan and rope

Capstan and rope



4. Platform

Folding platform



Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

5. Side warning lamps (each side has three units)

Side warning lamps



6. Wheel bracket

Wheel bracket



7. Operation Joysticks

Operation Joysticks



8. Side fence (Installed at two sides)

Side fence



Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

9. Tool box and accessories

Tool box



Chapter 4, Wrecker Truck with Crane Working Principles

The operator should fully understand Whole Structure and Working Principle for HOWO MATE 6x4 Recovery Truck with Boom Crane before any operation. Only trained person can operate this vehicle properly and to prevent unnecessary accidents and equipment damage.

i , How is the wrecker truck with crane working?

The wrecker truck with crane is refitted based on the HOWO 6x4 left hand drive chassis. The refit part mainly included XCMG SQS350 14Tons straight boom crane and platform. The engine power transit from PTO on gearbox to hydraulic oil pump, then hydraulic oil through the pump start from all control valves to hydraulic cylinders and hydraulic motors, which can make all system working normally.

- *14Tons straight boom crane assembly: which can be operated by crane control box, the working is relatively independent.*
- *Auxiliary frame is the base of all superstructure components, which can distribute the concentrated load of each component uniformly to the chassis frame, and improve the chassis bearing condition.*
- *Platform is the main part of the wrecker truck. The platform move backwards and tilting suitable angle, make sure the rear on land. Then the capstan and rope can towing cars loading on the platform, all hydraulic cylinders support the whole loading process.*
- *Wheel bracket mainly used for rescue work. Which make the wrecker truck rescue two cars at one time.*
- *Large toolbox as standard installed below platform, which mainly used for storage all necessary rescue accessories.*
- *Operation Joysticks installed at two side of the platform, which can make the wrecker truck working by using hydraulic joysticks. Also two sides Operation Joysticks design can make sure operator always at safety sides.*
- *Safety warning lamps installed on top of the platform, which can not only warning others during working, but also can protect the driver.*

ii How to operate wrecker truck with crane?. **(Very Important)**

1. Refer to Chapter 3 and get more information about superstructure component.

At co-driver side, near the operation joysticks installed Red Switch

**Please Note: When switch is PARALLEL with platform, wrecker platform working (Figure 1);
When switch is VERTICAL with platform, knuckle crane working (Figure 2).**




Figure 1: Red Switch parallel with platform



Figure 2: Red Switch vertical with platform

2. How to operate the 5Tons knuckle boom crane:

a) Red Switch turns to vertical position as below picture showing.


Red Switch vertical with platform




b) Kindly refer to the specified Manual of Loader Crane, model SQ5ZK2Q (New model SQZ105-3).

3. How to operate the wrecker platform:

a) Red Switch turns to parallel position as below picture showing.




b) Kindly refer to below wrecker truck working principle drawing.



Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
 Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

c) Refer to the Operation Joysticks English Guidance to operate the wrecker platform.



d) Operate Joystick 2 & 3, the Platform working (**Loading First Car**):

Press Joystick 2 to Slip Out position, the platform move backward, which move short distance; release Joystick 2 and press Joystick 3 to Lifting position, the platform move upward till to the extreme position; then release Joystick 3 and press Joystick 2 again till the platform touch the ground.




Platform touch the ground

(Picture showing is the position that cars can start loading on platform)

Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

e) Cars loading on the wrecker truck platform.

Option 1: Car with power: Drive directly to the platform, then use bandage fasten on the platform.



(Car drive to the platform, the folding angle design make loading more convenient)



Option 2: Car with no power: Use capstan and rope towing cars loading to the platform, then use bandage fasten on the platform.

Capstan and rope hook towing the cars loading on platform



Note: Capstan and rope working introduction



(Driver Position-----Co-Driver Position)

When switch turn to Driver Position, Capstan and rope working manually

When switch turn to Co-Driver Position, Capstan and rope working hydraulically

- f) *When cars well fasten on the platform, Operate Joystick 2 & 3, the Platform working:
 Press Joystick 2 to Slip In position, the platform move forward, which move short distance; release Joystick 2 and press Joystick 3 to Falling position, the platform move downward till to the extreme position; then release Joystick 3 and press Joystick 2 again till the platform back to normal model.*

g) Operate Joystick 4 & 5, the Wheel Bracket working (*Loading Second Car*):

Press Joystick 5 to Falling position, the wheel bracket move downward, which move short distance; release Joystick 5 and press Joystick 4 to Stretch Out position, the wheel bracket move out till to the extreme position; then release Joystick 4 and press Joystick 5 again till the wheel bracket landing on the ground.

Picture showing Wheel Bracket landing on the ground



h) The Wheel Bracket can be adjustable to be suitable for many sizes of wheels.

Tire holding system is moveable and adjustable when using



Tire holding system kept position when not using

The bracket can stretch out to suit for different sizes of tires

i) When towing car well fixed on wheel bracket, Operate Joystick 4 & 5, the Wheel Bracket working:
 Press Joystick 5 to Rising position, the wheel bracket move upward, which move short distance; make sure the car easy for towing.

Chapter 5, Others for Attention

After carefully reading the above information, you must be well known how to use the ISUZU 4*2 Wrecker Truck with Crane; below show some parts you need to pay attention while using the truck.

1. New Truck for Attention

As the new truck needs to pass the run-in period smoothly, so please take note for truck at the beginning of 100 hours:

- Lifting weight and Towing weight not exceed 70% of the rated weight, and maximum rope towing weights not exceed 70% of the rated one.
- Carefully checking all joints fasten situation before and after each operation.

2. Truck Driving for Attention

- All system retracts to initial position, the operation joysticks at middle position, and PTO must shut off.
- Wheel Bracket position cannot be too low, because it is not safety for driving.
- When wrecker truck full loading, the driving speed should be less than 30km/h, the speed should be lower special on turning position, going up and down position or in bad situation. Sharp turn and brake is forbidden.
- When reversing, the included angle for truck and car should be less than 70° , otherwise will damage the car.

3. Platform working for Attention

- Strictly following the Operation Guidance for using. No overloading.
- Before lifting the platform, press Joysticks 2 to Slip Out position, make sure the platform move backward firstly, which can drag the roller off the limit frame. When platform out of the limit frame, then can start lifting.
- Similarly, when platform falling down, press Joysticks 2 to Slip In position, make sure the platform move

Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

forward firstly, then falling to extreme position and move forward to initial place.

- *Make sure the Wheel Bracket at initial position before lifting the platform.*

4. Wheel Bracket working for Attention

- *Strictly following the Operation Guidance for using. No overloading.*
- *The wheel bracket is adjustable and moveable, which can make the bracket suitable for different tires, but overloading is strictly forbidden.*

5. Capstan and rope working for Attention

- *When capstan and rope towing cars loading on the platform, the rear legs on wheel bracket should be on solid ground.*
- *Towing position should be at rear of the platform, the towing angle less than 20 °*
- *Capstan under working condition, the rope should left 4-5 rings.*

6. Hydraulic system working for Attention

- *When operate the hydraulic control system manual joysticks and acceleration cable, should not drag too hard.*
- *Hydraulic oil should be same brand, mixing using is forbidden.*
- *When hydraulic oil temperature exceed 70 °C, the work should be stop.*

Chapter 6, Troubleshooting

Items	Trouble	Reason	Method
1	Hydraulic oil leakage	<ol style="list-style-type: none"> 1. Joint loosen 2. Sealing parts damage 3. Pipeline break 	<ol style="list-style-type: none"> 1. Fasten joint 2. Replace new seals 3. Change new pipes
2	Hydraulic oil pressure lower	<ol style="list-style-type: none"> 1. Hydraulic oil level too low 2. Suction pipe blocked 3. Oil pump damage or serious leakage 4. Overflow valve low open pressure 5. Oil pipe or actuator serious leakage 6. Pressure gauge damage (No data) 	<ol style="list-style-type: none"> 1. Add more hydraulic oil 2. Maintenance suction pipe 3. Maintenance oil pump 4. Adjust to suitable pressure 5. Maintenance oil pipe and actuator 6. Maintenance pressure gauge
3	Oil road too noisy	<ol style="list-style-type: none"> 1. Air exist inside of pipe 2. Suction pipe air leakage 3. Oil temperature too low 4. Filter blocker 5. Hydraulic oil not enough 	<ol style="list-style-type: none"> 1. Multiple working to exhaust air 2. Maintenance suction pipe 3. Idle working or change low viscosity hydraulic oil 4. Change filters 5. Add hydraulic oil
4	Oil road temperature too high	<ol style="list-style-type: none"> 1. Serious inside leakage 2. Overflow pressure too high 3. Working temperature too high or long time working 4. Balanced valve blocked 	<ol style="list-style-type: none"> 1. Maintenance actuator 2. Overflow pressure adjust to rated value 3. Stop working 4. Clean or change balanced valve
5	Pressure instability	<ol style="list-style-type: none"> 1. Overflow valve damping hole blocked or damping spring damaged 2. Balance valve damping hole blocked 3. Air exist in oil road 	<ol style="list-style-type: none"> 1. Cleaning or change new overflow valve 2. Cleaning or change new balance valve 3. Exhaust air
6	High oil pressure even unloading	<ol style="list-style-type: none"> 1. Oil road blocked 2. Filters blocked 	<ol style="list-style-type: none"> 1. Cleaning the oil road 2. Cleaning or change new filters
7	Oil cylinder shaking	<ol style="list-style-type: none"> 1. Air exist in air road 2. Balance valve damping hole blocked 	<ol style="list-style-type: none"> 1. Multiple working to exhaust air 2. Clean or change balanced valve
8	Accelerator not working	<ol style="list-style-type: none"> 1. Accelerator cable too long 2. Accelerator cable stuck 3. Engine throttle is locked 	<ol style="list-style-type: none"> 1. Adjust the cable length 2. Maintenance the accelerator cable 3. Unlocked the engine throttle

Chapter 7, Accessories

Items	Name	Picture	Quantity	Remark
1	Dragging fork seat		2 units	
2	Dragging fork		2 units	
3	L-shape tire holding system		2 units	Storage on the Wheel Bracket
4	Bandage		2 units	
5	V-shape hook		1 unit	

Factory: No 9, Jiliang Avenue, Economic Zone, Suizhou Hubei, China
 Tel: +86 136 4729 9000 Official Web: www.howotrucks.com Email: info@howotrucks.com

6	Towing trailer		2 units	
7	Standard ISUZU truck Tools		1 set	
8	Customer ordered spare parts			

howotrucks.com
 whatsapp: 0086 136 4729 7999